Sensor Cable Assembly Specifications

Soil Moisture Sensor:

Device: Acclima TDR-315H

Connector: M8, 3 pos

Connector PN: T4011008031-000 Cable Length: 5m (as supplied)

Pinout:


Pin	Wire
1	Red
3	White
4	Blue

Note: Pin 2 is not populated in the connector

Appendix A: Installation of M8 Connector

M8 Field Installable Connector

Unshielded Cable / 3-4-Position Connectors / Straight Connector





- 1. Connector components install on cable
- 2. Cable jacket should be stripped as shown
- 3. For 3-4-position, install wire to correct insert position
- 4. Turn the M2.0 screw with suitable tool, torque to 0.2Nm [1.77 in.-lb.]
- Install straight housing: first the groove must align with
 - With the housing rib, then screw insert nut with torque 0.4 Nm.
- 6. Install seal, pinch ring, pressing screw
- 7. Pressing screw should be tightened with torque

Taken from:

https://www.te.com/commerce/DocumentDelivery/DDEController?Action=showdoc&DocId=Specification+Or+Standard%7F114-137144-1_Rev.A%7FA1%7Fpdf%7FEnglish%7FENG_SS_114-137144-1_Rev.A_A1.pdf%7FT4011008031-000